

HIGH TACK APPLICATION TAPE

XP3078 50cm wide x 25m . XP3079 75cm wide x 25m

Our high tack application tape has more of a sticky backing than standard tape. Our application tapes are made for thermal transfer of printed textile films.

50cm & 75cm samples are available free of charge upon request.

STEP BY STEP

STEP 1

Print and cut design on the printable material. Once cut, weed away the excess material around the design.

STEP 2

Cut a piece of application tape slightly bigger than your design, peel the backing and carefully lay on top of the transfer.

STEP 3

Using a squeegee with pressure, flatten the application tape down and smooth out any bubbles.

STEP 4

Flip over the transfer and application sheet (now stuck together), and peel the backing off the printable media. Now only the weeded design should remain on the application tape.

STEP 5

Position the design onto the garment sticky side down (the sticky backing will aid the placement). Cover with a silicone sheet and press using the recommended settings.

COMPATIBILITY CHART

SOLVENT DARK TURBO

SOLVENT DARK PLUS

SUBLI BLOCK SOFT TURBO

NYLO PRINT MATT

COLOUR CUT

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of High Tack Application Tape be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. .